Guide for License Manager of VD SW Product

2014. 2. MagicInfo SW

Contents

VD SW List to be applied by the SLM License by Feb. 1 2014

- I. License Manager for Server Product
 - I. MagicInfo Server i/S/Lite
 - II. MagicInfo DataLink

- II. License Manager for Applications
 - I. MagicInfo VideoWall Console
 - II. MagicInfo VideoWall Author
 - III. MagicInfo Premium Author
 - IV. E-board IWB/IMS

License List - MagicInfo Premium Server

- I. License List for MagicInfo Premium Server
 - I. Charged License
 - I. MagicInfo Premium I Server
 - II. MagicInfo Premium S Server
 - III. MagicInfo Lite Server
 - IV. MagicInfo Premium Mobile
 - V. MagicInfo DataLink Server
 - II. Free License
 - I. MagicInfo Premium I Server (5 LFDs)
 - II. MagicInfo Premium S Server (conditional 60days, 5 LFDs)
 - III. MagicInfo Lite Server (25 LFDs)

DataLink license is divided from the MagicInfo Premium Server

DataLink License is entered to the DataLink Server from OCT. 2013

0. Help

- 1 After installing the latest Server version (above 2003.0)
- (2) No default license is included in the server.
- (3) The old license key(issued from www.samsunglfd.com) can't be used in the New Server version
- (4) The new License Key can be issued from https://v3.samsunggsbn.com
- (5) Refer to the SLM Guide document.


If you type http:// your server ip:7001/MagicInfo, You can get this screen because you don't have any license.

Click OK. And follow the steps of register the license.



2. Start


- 1 Click Setting Menu ,and Click SIM License Info.
- 2) Show the Menu of License Manager




3. Activate the free license key(Free License)- OnLine

1 Click Free License

- The Free License Key is not activated repeatedly VD SW support to activate the free License without logging in the SLM Server.
- Select one of Product Name
- (3) Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- 4 Enter your data
- 5 Click Next, check the Success window and you can see the added license key








3. Activate the free license key(Free License)- OFFLine


- (1) Click Free License
- (2) Select one of Product Name
- The Free License Key is not activated repeatedly VD SW support to activate the free License without logging in the SLM Server.
- (3) Select "disconnected" of internet Connection (in case not networked or failed in connected)
- Copy the license key and HW unique key, go to the SLM Site
 - input license key and HW key in the SLM site, and then download the Activation key in the local.
- Input the Activation key in the SW Program, Click Next




3. Activate the charged license key(First Time Activation)- OnLine

To activate the charged license Key (Not the free license key)

- 1 Prepare the charge license key from https://v3.samsunggsbn.com
- (2) Click First Time Activation
- (3) Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- 4 Enter your license Key
- (5) Click Next, check the Success window and you can see the added license key








3. Activate the charged license key(First Time Activation)- OffLine

To activate the charged license Key (Not the free license key)

- Prepare the charge license key from https://v3.samsunggsbn.com
- 2 Click First Time Activation
- $oxed{3}$ Select "disconnected" of internet Connection (in case not networked or failed in the connected way)
- 4 Enter your license Key, copy the license key and HW Unique key, go to the SLM Site
 - input license key and HW key in the SLM site, and then download the Activation key in the local.
- Click Next, check the Success window and you can see the added license key





4. Additional Activation -Online

The Free License Key is not applied to the Addition Activation.

To extend the license volume, extend the current key, Do not issue the new key. You nee to pay it.

- 1 Extend the volume of license key from https://v3.samsunggsbn.com
- (2) Click the Additional activation. (After completing the billing for the extention)
- 3 Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- 4 Click Next, check the Success window and you can see the added license key







4. Additional Activation - Offline

The Free License Key is not applied to the Addition Activation.

To extend the license volume, extend the current key, Do not issue the new key. You nee to pay it.

- 1 Extend the volume of license key from https://v3.samsunggsbn.com
- (2) Click the Additional activation. (After completing the billing for the extension)
- (3) Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- (4) Copy the license Key and HW key, go to the SLM , Issue the Activation key from the SLM
- 5 Input the Activation Key, check the Success window and you can see the added license key








5. Return License - OnLine

The Free License Key is not applied to the Return License.

To move the license key to the another PC, you need to return the license in current PC, and activate the license key in the New PC

- 1 Click the Return License
- (2) Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)

3 Click Next, check the Success window and you can't see the deleted license key in the list








5. Return License - OffLine

The Free License Key is not applied to the Return License.

To move the license key to the another PC, you need to return the license in current PC, and activate the license key in the New PC

- 1 Click the Return License
- 2 Select "disconnected" of internet Connection (in case not networked or failed in the connected way)
- (3) Copy the Deactivation request key. Go to the SLM



License List - MagicInfo Application

- I. License List for MagicInfo VideoWall Console
 - I. Charged License
 - I. MagicInfo VideoWall I Console
 - II. MagicInfo VideoWall S Console
 - II. Free License
 - I. MagicInfo VideoWall I Console (Conditional 60days, 5LFDs)
 - II. MagicInfo VideoWall S Console (Conditional 60days, 5LFDs)
 - III. MagicInfo VideoWall Console Mobile
- II. License List for MagicInfo VideoWall Author
 - I. Charged License
 - I. MagicInfo VideoWall I Author
 - II. MagicInfo VideoWall S Author
 - II. Free License
 - I. MagicInfo VideoWall I Author (Conditional 60days)
 - II. MagicInfo VideoWall S Author (Conditional 60days)
- III. License List for MagicInfo Premium Author
 - I. Free License
 - I. MagicInfo Premium Author

License List - E-board Solution


- I. License List for E-board
 - I. Charged License
 - I. E-board IWB
 - II. E-Board IMS
 - II. Free License
 - III. Special caution
 - I. Multi-Screen (IWB): Combine by Maximum 4 lfds. Possible only in the Off-Line connection.

When you make the Activation Key in the SLM Server, select how many lfds for the multiscreen.


I. If the license key of the IWB is on the same network, the license key of IMS doesn't need

0. Help

- 1 After installing the latest magicInfo appliction version (above 2003.0)
- 2 No default license is included in the server.
- (3) The old license key(issued from www.samsunglfd.com) can't be used in the New Application
- 4 The new License Key can be issued from https://v3.samsunggsbn.com
- (5) Refer to the SLM Guide document.



If you execute the MagicInfo solution You can get this screen because you don't have any license.




2. Start


- 1 Click the Help Menu ,and Click the License Manager
- 2 Show the Menu of License Manager



3. Activate the free license Key-Online


- 1 Select one of product and Click Free License
- The Free License Key is not activated repeatedly VD SW support to activate the free Licenwithout logging in the SLM Server.
- 2 Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- (3) Enter your data
- (4) Click Next, check the Success window and you can see the added license key





3. Activate the free license Key-Offline


- 1 Select one of product and Click Free License
- The Free License Key is not activated repeatedly VD SW support to activate the free Licenwithout logging in the SLM Server.
- (2) Select "disconnected" of internet Connection (in case not networked or failed in the connected way)
- (3) Copy the license key and HW unique key, go to the SLM Site
 - input license key and HW key in the SLM site, and then download the Activation key in the local.
- Input the Activation key in the SW Program, Click Next



3. Activate the charged license key(First time Activation)-online


To activate the charged license Key (Not the free license key)

- 1) Issue the charge license key from https://v3.samsunggsbn.com
- 2 Select one of product and Click First Time Activation
- 3 Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- 4 Enter your license Key
- (5) Click Next, check the Success window and you can see the added license key



3. Activate the charged license key(First time Activation)- offline

- To activate the charged license Key (Not the free license key)
- Issue the charge license key from https://v3.samsunggsbn.com
- 2 Select one of product and Click First Time Activation
- Select "disconnected" of internet Connection (in case not networked or failed in the connection way)
- (4) Copy the license key and HW unique key, go to the SLM Site
 - input license key and HW key in the SLM site, and then download the Activation key in the local.
- Input the Activation key in the SW Program, Click Next




4. Additional Activation- online

The Free License Key is not applied to the Addition Action.

To extend the license volume, extend the current key, Do not issue the new key. You nee to pay it.

- 1 Extend the volume of license key from https://v3.samsunggsbn.com
- (2) Click the Additional activation.
- (3) Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- (4) Click Next, check the Success window and you can see the added license key




4. Additional Activation- offline

The Free License Key is not applied to the Addition Action.

To extend the license volume, extend the current key, Do not issue the new key. You nee to pay it.

- 1 Extend the volume of license key from https://v3.samsunggsbn.com
- (2) Click the Additional activation.
- (3) Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- (4) Click Next, check the Success window and you can see the added license key




5. Return License-online

The Free License Key is not applied to the Return License.

To move the license key to the another PC, you need to return the license in current PC, and activate the license key in the New PC

- 1 Click the Return License
- Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- 3 Click Next, check the Success window and you can't see the deleted license key in the list.



5. Return License -offline

The Free License Key is not applied to the Return License.


To move the license key to the another PC, you need to return the license in current PC, and

activate the license key in the New PC

Click the Return License

- Select "connected" of internet Connection (if this pc is not networked, follow the Disconnected way)
- 3 Copy the Deactivation request key. Go to the SLM


(4) Input the Deactivation Request key.



Error code List

Error Code	Error Message	Error Code	Error Message
11000	License Key does not exist	14000	An Error occurred while generating activation key
11001	Hardware Unique Key does not exist	15000	No license key and hardware unique information.
11002	DeActivation key does not exist	19000	An error occurred while processing
12000	License generation data not found	19001	This hardware is already activated.
13000	It exceeds the activation limit. - This License Key was already activated somewhere - If same PC, get the Activation key from SLM,	19002	No Activation data.
10	HTTP Connection Failed - Try this url whether the login screen is viewed. http://v3.samsunggsbn.com or http://v3.samsunggsbn.com		

SLM - Search the license key



SLM - Display Solution Download Center

